

It's simply faster to install

This compact panel is perfect for residential and small commercial installations



Place Your Logo Here

This wireless and cellular panel has been reduced to nearly 3 X 5 inches — our smallest panel ever, but it's still packed with almost all of the popular security features of our full-size DMP panels..

- Designed for fast, reliable installations, without pulling a single wire
- Increase your RMR with cellular communication
- On-board cellular communications allows In Touch™ Messaging Features for any cell phone
- 28 wireless zones with pre-named zones
- Supports up to 8 two-way wireless key fobs or two-way wireless outputs
- Supports 4 fully functional two-way wireless keypads
- Supports fully functional two-way wireless sirens

XTL™ WIRELESS BURGLARY CONTROL PANEL

- Grab-install-go— XTL is wireless
- Plastic enclosure can be easily wall mounted or located on a shelf and can be customized with your logo printed on the light pipe
- Uses DMP SecureCom Wireless, LLC Cellular Communications
- In Touch™ Messaging Feature transmits panel alerts to up to three destinations and lets the user send panel commands, all via text message
- Provides recurring revenue opportunities
- All/Perimeter, Home/Sleep/Away or 6 Area system
- 30 user codes with authority levels
- 100-event memory
- Supports up to four two-way wireless LCD 9000 Series keypads
- Arm only, ambush code, and temporary user code options
- Built-in standby battery
- Built-in English text programming from any LCD keypad
- Selectable automatic arming and disarming
- Open/Close schedules with Closing Check
- Late to Open/Early to Close and Traffic Count features for retail installations
- Attrition Detection™ monitors system for arming activity
- Programmable User Inactivity Monitor watches for on-site activity
- Remote program/download with Remote Link™ over cell using SecureCom Wireless



Digital Monitoring Products

RECEIVER 1 & 2 OPERATION

Select one or two receivers for messages regarding alarms, supervisory/trouble, opening/ closing, and test reports. Send all messages to both receivers or identify one receiver for alarms and second for reports or trouble messages to alert only the proper responder.

ON-BOARD CELLULAR (GPRS) COMMUNICATION

The GPRS interface provides a dependable cellular communication link to two IP addresses. The interface works on digital cellular GSM/GPRS data networks in the USA and Canada. Cellular connections are less likely to be affected by weather and can't be cut, providing greater security than traditional land-line dial-up connections. Cellular transmission is a great solution for installation sites without a land line or currently using VOIP lines.

ONE-STOP CELLULAR

SecureCom Wireless, LLC provides a reliable wireless solution for the XTL's transmission of alarm signals to the Central Station receiver.

DATA OVERAGE

Data overage suppression provides a safeguard against unexpected cellular overage charges. Only a certain volume of alarm messages per hour are sent via the cellular path. This feature is a DMP exclusive!

SIMPLE ARMING

XTL provides multiple arming configurations: Area arming with six separate areas; All/Perimeter arming with perimeter and interior areas; or Home/Sleep/Away arming with perimeter, interior, and bedroom areas. Users can arm the perimeter and interior at night while leaving the bedroom area disarmed.

CUSTOMERS STAY "IN TOUCH™"

CONTROL THE SYSTEM

The DMP In Touch Messaging Feature lets users send commands via text messages to their panel. Residential and smaller commercial users can now remotely control their systems, including the ability to arm or disarm their system, control outputs, retrieve system status, and perform other functions. Each command received by the panel is acknowledged back to the user via return SMS Message.

Messages users can send include:


- AWAY/ARM ALL - allows user to turn all areas of their system on or off
- PERIM - allows user to arm only the perimeter
- ARM (area number) - allows user to arm only selected system areas
- DISARM - allows user to turn all areas of their system off
- DISARM (area number) - allows user to disarm only selected system areas
- CANCEL - allows user to cancel an alarm
- STATUS - allows user to see status of their system, e.g. ARMED, READY, ALARM, and others

CHECK SYSTEM STATUS

Users can be informed of alarm system activity and status. The panel transmits text messages regarding alarms, troubles, and arming/disarming events. The GPRS/ SMS messages can be directed to as many as three cell phone numbers. Messaging can be configured via Remote Link™ or from the keypad. This option can be enabled in panel programming, providing an excellent opportunity for additional recurring revenue.

The transmitted messages are:

- Zone Alarms by Zone Name
- Zone Troubles by Zone Name
- Zone Bypass by User
- Arming (Closings) by User
- Disarming (Openings) by User
- Late to Close
- AC Power Trouble and Restoral
- System Low Battery and Restoral
- Ambush
- Abort, Cancel, and Alarm Verified by User
- Check-in by User



Use any model of cell phone for In Touch Messaging



ON-BOARD WIRELESS

The XTL Control Panel includes a Wireless Receiver on-board supporting the 1100 Series wireless devices. These 900MHz frequency-hopping, spread-spectrum devices feature two-way communication for superior operation, supervision, and battery life. Two-way communication minimizes repetitive signaling and helps to quickly identify missing transmitters.

With 28 wireless zones the transmitter options are more than sufficient for any install. The industry's only PIRs that are configurable over the air, 8 key fob zones or 8 wireless outputs including arm/alarm LED, wireless sirens, and wireless relays make the XTL a perfect choice for residential or small commercial applications.

1135 WIRELESS SIREN

The 1135 Wireless Siren makes it possible to quickly and easily place one or more sirens as part of an installation. With both residential and commercial end users, this battery powered siren is an easy, add-on sale to customers who want the extra security provided by locating sirens in several interior locations. The 1135 includes a cover tamper and survey LED, and comes with batteries.



9000 SERIES WIRELESS KEYPAD

The 9060 and 9063 Wireless Keypads are fully functioning, supervised keypads that provide installation flexibility. These full-feature keypads include four 2-button panic keys and an internal speaker. The backlit keyboard is easy to read, and both the keyboard and logo turn Red in alarm conditions, providing a visual alert. Both Keypads have a 32-character display, and can be programmed with a 16-character home or business name. The 9063 keypad also includes a built-in proximity reader for codeless arming and disarming.



CANCEL/VERIFY™

Get a faster response to genuine emergencies and quickly cancel accidental or false alarms. When an alarm sounds, the user can silence it without disarming the system. After assessing the situation, the user can press the appropriate button to CANCEL the alarm or VERIFY the alarm, sending an alarm verification message to the Central Station, eliminating the need for a confirmation phone call.

HOME/SLEEP/AWAY

For residential applications, the homeowner can press one button to select each of three separate system arming options. They can select HOME to arm the perimeter of the home, but allow for movement within the house. Select SLEEP to arm the perimeter and only specified areas inside their home, leaving sensors near bedrooms disarmed. Selecting AWAY fully arms all elements of the system.

ALL/PERIMETER

In business applications, system users can quickly select ALL to completely arm the system as they leave the facility for the day. They also have the option to select PERIMETER, arming all exterior sensors at doors and windows, but disarming all interior sensors so employees can move freely around the facility.

BUILT-IN PROGRAMMER

An internal English-text programmer enables technicians to easily program and test the panel from any keypad. A lockout code restricts access to only authorized persons.

KEYPAD SHORTCUT KEYS

Keypad shortcut keys simplify operation and allow the user to more quickly arm, check in, monitor, exit, or reset the system. One-button arming creates the simplest keypad operation available. Use the one-button shortcut keys for common functions or use the ATM style menu for advanced functions, whichever method meets the user's needs or level of expertise with the system.

USER CODES

Program up to 30 codes. Assign a Standard or Master Authority level to control each user's level of access to the system, with scheduled and limited users.

ATTRITION DETECTION™ PROMPTS YOU TO CALL YOUR CUSTOMER

The exclusive DMP Attrition Detection feature gives you advance warning that a customer may be preparing to cancel their monitoring contract. With this feature activated, you will receive a notification if there has been no system activity for the number of days you select.

CROSS ZONING

This powerful, false-alarm-reduction feature allows zones to be cross-zoned and report alarms only when two or more zones fault within a programmable time of 4 to 250 seconds. Should just one zone trip, only a zone fault report is sent to the Central Station.

EVENT MEMORY

The XTL panel logs up to 100 user and system events that you can view at any time through a keypad User Menu option. The Display Events feature allows users to view stored events such as openings and closings, zone events, user code changes, and supervisory events.

ZONE INACTIVITY

With Zone Inactivity, you can easily monitor a person living alone. If there is no activity at the premises within the programmed number of hours, the system transmits an SMS message to your PDA and/or cell phone. The Central Station also receives an alert. It's a valuable feature for customers looking after aging adults.

ZONE AUDIT

The Zone Audit feature allows programming the panel to send an alert when the sensor fails to trip within the specified number of days. This feature helps identify potential sensor problems, including sensors deactivated to bypass faults or blocked sensors.

WIRELESS KEYPAD ASSOCIATION

This is a great time-saver for installers. Any keypads not associated with another panel are accepted and assigned to the first open keypad address available. Keypads are automatically assigned based upon the order in which they are detected. A maximum of four keypads may be associated with a panel.

REMOTE PROGRAMMING

Remotely program panels using DMP Remote Link software. Upload panel programming, make the necessary programming change, and then download the revised programming into the panel.

FOR RETAIL INSTALLATIONS

The Late to Open/Early to Close feature sends a message to the Central Station if the facility isn't opened on time or closed before the scheduled time. The Traffic Count sends a daily tally of trips for the specified zone.

With the Receiver 1 & 2 operation, Auxiliary 1 & 2 Zone messages can be sent to a specific receiver, enabling retail clients to alert a specific guard station of potential shoplifting in a certain area or other type of notifications.

POWERING THE PANEL

The panel is powered by a small 12V plugin power supply with standby battery operation.

KEYPADS

- 9060-W Wireless Keypad
- 9060-W/699 Wireless Keypad with Deskstand
- 9063-W Wireless Keypad with Prox Reader
- 9063-W/699 Wireless Keypad with Prox Reader and Deskstand
- 699 Keypad Deskstand

CELLULAR

- 380-400 Replacement Level 400 SIM Card

CENTRAL STATION RECEIVERS


- SCS-1R Security Control Receiver

COMPUTER SOFTWARE

- Remote Link Programming Software
- System Link End-User Management Software
- Link Server Application

DMP WIRELESS

- 1100R Repeater
- 1101 Universal Transmitter Internal and External Contacts
- 1102 Universal Transmitter External Contact
- 1103 Universal Transmitter External Contact
- 1105 Universal Transmitter Internal and External Contacts
- 1114 Four-Zone Expander
- 1116 Relay Output
- 1117 LED Annunciator
- 1121 Pet Immune PIR Motion Detector
- 1125 PIR Motion Detector
- 1126C Ceiling Mount Curtain PIR
- 1126R 360 Ceiling Mount PIR
- 1126W Wide Angle Ceiling Mount PIR
- 1127C Wall Mount Curtain PIR
- 1127W Wall Mount Wide Angle PIR
- 1129 Glassbreak Detector
- 1131 Recessed Contact
- 1135 Siren
- 1139 Bill Trap
- 1142 Two-Button Hold-up Transmitter
- 1142BC Two-Button Belt Clip Hold-up Transmitter
- 1145 Four-Button Key Fob
- 1146 Two-Button Key Fob
- 1147 One-Button Key Fob
- 1161 Wireless Smoke with Sounder
- 1162 Wireless Smoke and Heat Detector



XTL Circuit board

SYSTEM SPECIFICATIONS

Primary Power	12 VDC (Model 372-500)
Secondary Power	3.7 VDC lion Polymer Battery
Enclosure	ABS Plastic
Dimensions:	5.5" W x 3.75" H x 1" D

LISTINGS AND APPROVALS

Refer to the XTL Series Installation Guide, Programming Guide and specific compliance listings for installation and programming requirements necessary to meet a particular approval.

California State Fire Marshal (CSFM)

ETL
ANSI/SIA CP-01-2007 False Alarm Reduction

FCC Cellular Listings
FCC ID: MIVGSM0308
Industry Canada ID 4160A-GSM0308

FCC Wireless Listings
FCC ID CCKPC0117
Industry Canada ID 5251A-PC0117.

Underwriters Laboratories (UL) Listed
ANSI/UL 1023 Household Burglar
ANSI/UL 985 Household Fire Warning
ANSI/UL 1610 Central Station Burglar

For additional information, access www.dmp.com and select Compliance.



quality. integrity. innovation.

